

## Finish Selection



## Swing and Handing Selection

**INTERIOR OF HOUSE**

**EXTERIOR OF HOUSE**

Left Hand Inswing

When you stand with your back against the hinges of the active (moving) door panel, if the door opens to the left and swings into the house, you need a **LEFT HAND INSWING ASTRAGAL**.

**INTERIOR OF HOUSE**

**EXTERIOR OF HOUSE**

Right Hand Inswing

When you stand with your back against the hinges of the active (moving) door panel, if the door opens to the right and swings into the house, you need a **RIGHT HAND INSWING ASTRAGAL**.

**INTERIOR OF HOUSE**

**EXTERIOR OF HOUSE**

Left Hand Outswing

When you stand with your back against the hinges of the active (moving) door panel, if the door opens to the left and swings out of the house, you need a **LEFT HAND OUTSWING ASTRAGAL**.

**INTERIOR OF HOUSE**

**EXTERIOR OF HOUSE**

Right Hand Outswing

When you stand with your back against the hinges of the active (moving) door panel, if the door opens to the right and swings out of the house, you need a **RIGHT HAND OUTSWING ASTRAGAL**.

**Astragals should be ordered based on the handing and swing of the active (moving) door panel.**